AQUASCAPER10261191MAN







INSTALLATION AND INSTRUCTION MANUAL

This product requires Manual Handling. Know your limitations before lifting!



For guidance please refer to: hse.gov.uk/toolbox/manual.htm

IMPORTANT

Never attempt to clean the aquarium with a sharp, blade-like object as this may damage the silicone bond and invalidate the warranty.


IMPORTANT

It is important to ensure that any water that is spilled onto the decorative panels is wiped off and dried immediately. Failure to do so will invalidate the warranty.

WARNING: PLEASE READ THE FOLLOWING SAFETY INFORMATION FIRST.

DANGER: To avoid a possible electric shock, ensure all electrical devices are switched off when carrying out maintenance. Take extra care when handling a wet aquarium. Do not attempt repairs yourself; return the appliance to the place of purchase for service or dispose of the appliance.

 To avoid the possibility of the appliance plug or socket getting wet, position the aquarium cabinet and tank to one side of a wall mounted socket to prevent water from dripping onto the socket or plug. You should create a "drip loop" for each cord connecting an aquarium appliance to a socket. The "drip loop" is that part of the cord below the level of the socket, or the connector. Use an extension cord, if necessary, to prevent water travelling along the cord and coming into contact with the socket.



- Always unplug an appliance from an outlet when not in use, before putting on or taking off parts, and before cleaning. Never pull the cord itself to remove the plug from the outlet. Hold the plug and pull to disconnect.
- If the plug or socket does get wet, **DO NOT unplug the cord**. Disconnect the fuse or circuit breaker that supplies power to the appliance. Then unplug the device and examine for presence of water in the socket.
- Close supervision is necessary when any appliance is used by or near children.
- Do not use an appliance for anything other than its intended use. The use of attachments not recommended or sold by the appliance manufacturer may cause an unsafe condition.
- Do not install or store the appliance where it will be exposed to the weather or to temperatures below freezing point.
- Make sure an appliance mounted on a tank is securely installed before operating it.

Read carefully all the important notices on the appliance and the corresponding instruction manual.

NOTE: A cord rated for less amperes or watts than the appliance rating may overheat. Care should be taken to arrange the cord so that it cannot be tripped over or pulled accidentally.

IMPORTANT

It is important to ensure that any water that is spilled onto the decorative panels is wiped off and dried immediately. Failure to do so will invalidate the warranty.



Congratulations on purchasing a The Aquascaper aquarium by Evolution Aqua.


The combination of the finest low iron glass, high polishing techniques and near perfect silicone work come together to provide a nearly invisible tank which will enhance and highlight the aquascape within it.

The Aquascaper aquariums and cabinets are built from the highest quality materials, ready to be equipped and installed at your convenience.


PLEASE READ THIS MANUAL CAREFULLY BEFORE SETTING UP.




SPECIFICATIONS




300 AQUARIUM 5mm Glass 300mm (I) x 300mm (w) x 300mm (h) Nett System Volume: 21 litres




900 AQUARIUM 10mm Glass 900mm (I) x 500mm (w) x 450mm (h) Nett System Volume: 186 litres



600 AQUARIUM 8mm Glass 600mm (I) x 500mm (w) x 360mm (h) Nett System Volume: 99 litres



1200 AQUARIUM 12mm Glass 1200mm (I) x 600mm (w) x 450mm (h) Nett System Volume: 297 litres



1500 AQUARIUM 15mm Glass 1500mm (I) x 600mm (w) x 550mm (h) Nett System Volume: 448 litres 1800 AQUARIUM 19mm Glass 1800mm (I) x 600mm (w) x 550mm (h) Nett System Volume: 575 litres

INSTALLATION ADVICE

Build your eaFreshwater aquaFrame cabinet using the assembly instructions provided.

PLEASE NOTE: Your finished aquarium should be away from doors and radiators, out of direct sunlight and near to, but not directly over, power sockets.

POSITIONING THE CABINET

One litre of water weighs one kilogram (1kg) so your furnished aquarium with sump will weigh at least as much in kilograms as its total volume in litres.

THE CABINET MUST BE PLACED ON A STRONG, LEVEL FLOOR. ENSURE YOU HAVE ADJUSTED ALL THE CABINET FEET TO ENSURE THE CABINET AND AQUARIUM ARE COMPLETELY LEVEL AS SHOWN IN THE CABINET ASSEMBLY INSTRUCTION MANUAL.

INSTALLING THE TANK

Using a minimum of two people for the Aquascaper 300, 600 and 900 and four people for the 1200, 1500, 1800 place the aquarium slowly onto the cabinet top, ensuring that the protective base mat is sandwiched between cabinet top and tank base. (On the 300 aquarium the user will need to fit the base mat supplied). The rear corners of the aquarium should exactly line up with the rear corners of the cabinet. The sides should also exactly line up, producing a smooth line. The aquarium should protrude over the front of the cabinet top, but align with the cabinet perimeter when the cabinet doors are closed.

ADJUSTING THE CABINET DOORS

NOTE: ONLY ADJUST DOORS AT THE END OF THE INSTALLATION AND WHEN THE TANK IS FILLED WITH WATER.

The soft-close hinges have two points of adjustment. If necessary, adjust them until the door(s) are level, with an even gap, and close without any obstruction. The push-openers can also be adjusted by twisting them in or out, by hand.

CABINET CUT-OUTS

Your The Aquascaper cabinet comes with circular cut-outs in the sides. These are so that external filter pipework, CO2 hose and lighting cables can enter and exit the cabinet neatly, for side mounting, so that the rear view of the aquascape is not obstructed.

The cut-out itself comes with a removable insert, which is itself adjustable in orientation or can be removed entirely leaving the silver, steel effect trim, and maximum width in the cut-out for larger external filter hoses.



WARRANTY

Evolution Aqua warrants your product against defects in materials and workmanship for a period of 12 months, valid from the date of original purchase and will repair this product free of charge **(not including shipping costs)** with new / rebuilt parts.

The guarantee **DOES NOT APPLY** in case of improper use, negligence, lack of maintenance or accidental damage to the aquarium or cabinet. Damage to the aquarium glass is not included in the warranty. Damage to the silicone caused by incorrect cleaning, such as using a sharp object to clean the glass, will also invalidate the warranty.

The pre-condition for the warranty is that the stipulated set-up routine is observed. In the event that a problem develops with this product during or after the warranty period, contact the retailer from whom you originally purchased the item from. The retailer will then liase with Evolution Aqua Ltd to organise for the warranty procedure to be undertaken.

The warranty is extended only to the original purchaser.

Proof of date of purchase will be required before any warranty work can be carried out.

This warranty only covers failures due to defects in materials or workmanship which occur during normal use. It does not cover damage which occurs in shipment or failures which result from misuse, abuse, neglect, improper installation, operation, mishandling, misapplication, alteration, modification or service by anyone other than an authorised Evolution Aqua dealer.

The cabinet decorative panels are not waterproof and it is important to ensure that any water that is spilled onto the panels is wiped off and dried immediately. Failure to do so will invalidate the warranty. Do not allow any amount of water to collect on any part of the cabinet. Any sort of water damage on the cabinet is not covered under warranty.

Evolution Aqua shall not be liable for incidental or consequential damages resulting from the use of this product, or arising out of any breach of this warranty. All express and implied warranties, including the warranties of saleability and fitness for particular purpose, are limited to the applicable warranty period set forth above.

The installation and use of your product outside of our recommendations as printed in this manual may also void the warranty.

These statements do not affect the statutory rights of the consumer.



INNOVATION IN WATER



Evolution Aqua Ltd

Evolution House, Kellet Close Wigan, Lancashire, United Kingdom WN5 0LP

t: +44 (0) 1942 216554 f: +44 (0) 1942 418489 e: info@evolutionaqua.com w: www.evolutionaqua.com