





## SURGE SPARE PARTS



ITEM NO.	PART CODE	DESCRIPTION
1	<a href="#">CUV-118</a>	COMPLETE 18 WATT UVC INC. BULB, QUARTZ, O-RING AND BALLAST
1a	<a href="#">CUV-118 BALLAST</a>	18 WATT UVC BALLAST (NO BULB OR QUARTZ)
1b	<a href="#">CUV-118 QUARTZ SLEEVE</a>	QUARTZ GLASS SLEEVE FOR CUV-118
1c	<a href="#">1000-957</a>	CUV-118 O-RING
2	<a href="#">5300-005</a>	STAINLESS STEEL MOUNTING BRACKET
3	<a href="#">1000-951</a>	NITRILE O-RING
4	<a href="#">K25-51-32</a>	BALL VALVE
5	<a href="#">HOSETAILCLEAR</a>	CLEAR HOSETAIL FOR INLET
6	<a href="#">K22-90-23</a>	BLACK HOSETAIL FOR OUTLET
7	<a href="#">SURGEWSA</a>	SURGE WASTE VALVE ASSEMBLY
8	<a href="#">HOSETAILBLACK</a>	THREADED ELBOW FOR WASTE ASSEMBLY
9	<a href="#">CLEARHOSE 25</a>	50CM LENGTH OF CLEAR HOSE